



Press the **“ON”** button in the top left corner and **TAP** the tablet to wake the screen.



Connect your device by using either the **HDMI** or **VGA** cable.

*Note: **VGA** input requires 3.5mm audio connection.
Only use adapters if your device does not have **HDMI** or **VGA**.*

When ready, push the **SHARE** button on the tablet.



The **volume** and **mic** mute keys on the tablet control the **speaker** volume and **mic** mute in the room.

Press the **“OFF”** button when you are done using the system.



Contact Facilities for any questions or concerns, 650-724-3333.